

Electric Manual

Thor



ORIGINAL INSTRUCTION

Code:	
-------	--

Year:	2020
-------	------

Rev.:	01
-------	----

www.alfadispenser.com

3. ELECTRIC REPAIRING OPERATIONS


3.1. DIAGNOSIS AND ELECTRONIC PART DESCRIPTION

3.1.1. PC LINUX BOARD


The machine is provided with a PC board (Linux or Raspberry Pi) on which the high-level machine software is memorised.

The Linux PC board receives the Ethernet connection from the outside (LAN1 port) and is internally connected to the Main board (refer to next paragraph) via RS-232. The Linux board has RS-232 and USB ports necessary to connect some accessories like the scale.

The Linux PC board is powered with 12V.



The Raspberry Pi board, present as an alternative to the Linux board, features the same functions.



3.1.2. MMT BOARD


MMT is the Main board on which machine management firmware is saved. The orders sent by the high-level software are managed at MMT level. This board organises the machine cycle by interrogating and sending orders via RS-485 to the slave boards of the single circuits.

MMT board receives the external 48Vdc and 24Vdc power supplies, while it internally generates the 5Vdc and 3.3Vdc voltages.

DL1 = +5V
DL2 = +3.3V
DL9 = +48V

MMT also directly controls many actuators and sensors, as summarised in the table below:

CN5 is used for firmware programming via USB with bootloader (refer to chapter 4 – PROGRAMMING THE ELECTRONIC BOARDS)



3.1.3. SCCB BOARD

Each circuit, not directly piloted by the Main board, is managed by a dedicated SCCB board addressed according to the machine configuration set in the software.

Each board is powered with 24 V (two separate lines for logics and power) and 48V, controls the digital sensor inputs and integrates the control drivers of two DC 24V peripheral units (DC motor stirring and/or electrovalves) and of one stepper motor.

The board generates the necessary on-board service voltage. To facilitate the diagnosis, each power supply features a status LED (on = power connected):

DL11 = 3.3V

DL12 = 5V


DL10 = 15V

In case one or more power supply LEDs is OFF, check the fuse relevant status (see para. 3.2).

Likewise, the CN13 and CN11 outputs have a status LED that indicates when they are powered.

Following is a list of the controls of each SCCB board.

The CN1 connector, now no longer in use, was dedicated to firmware programming and updating through PICKit (refer to chapter 4 – PROGRAMMING THE ELECTRONIC BOARDS).



CIRCUIT	CN2	CN5	CN6	CN8	CN9	CN11	CN12	CN13
SLAVE PUMP3..4	STEPPER	HOME PHOT.	RS485	RS485		E.VALVE	PWR	STIR MOT
SLAVE PUMP5	STEPPER	HOME PHOT.		RS485		E.VALVE	PWR	STIR MOT
DOUBLE GROUP	STEPPER	HOME PHOT.	RS485	RS485		E.VALVE M	PWR	E.VALVE S

3.1.4. SPB BOARD

The SPB board is powered at 24Vdc and produces 12Vdc on board. These power supplies are also used to power the Linux board and any accessories. It is only used in combination with Linux board, not with Raspberry Pi.


In case of machine shut-off or power failure (voltage interruptions or dips), the SPB board has the function to keep the Linux board powered at 12V for the time necessary for the controlled shutdown of the operating system.

A 16.8V - 1800mAh NI-MH battery is used to store the 12V power: it features a safety PTC inside and is connected to the board at CN7.

The board features two inner fuses:

- F2=0.5A on recharge branch (protection against a charging current higher than the maximum allowed by the battery);
- F3=2.5A on the battery (protection in case of excess power absorption).

The DL1 LED indicates the presence of 12V voltage.




3.1.5. HUTTS BOARD

The HUT_TS board (1) is the board supporting the temperature sensor TC72 used to monitor the temperature of the products (colorants and bases).

The board is located inside the cabinet, fixed on the back of the colorant support base.

The signal is acquired by the MMT board.



3.2. CHECKING AND REPLACING THE NETWORK FUSES

In case of mains malfunction or problems, the safety fuses could blow and cut power.

Fuses are located in the fuse holder built in the plug with switch on the back panel.

To replace the interrupted fuse open fuse holder using a flat screwdriver to prise it open.

Remove the fuse and its holder and install a new fuse.



USE ONLY FUSES OF THE SAME TYPE AND THE NOMINAL RATING SHOWN IN THE PRODUCT LABEL.

Fuse requirements:


EU - IEC 60127 Approval

US - UL248-1 and UL248-14 Approval

3.3. REPLACING THE SECONDARY CIRCUIT FUSES (INTERNAL TERMINAL BOARDS)

In case of malfunction or faults, the safety fuses could interrupt the output power supply of the terminal boards. The fuses are located on the terminal boards located inside the rear electric compartment (see chapter 2 - ACCESS TO THE ELECTRIC PARTS).

- In order to replace the fuses, proceed as follows:
- Remove the rear panel as described in chapter 2 - EXTERNAL COVER REMOVAL to reach the fuse carrier terminal boards (1).



- Find the circuit of the interrupted power supply line and take a fuse with a correct rating according to the diagram to the side.
- Lift the fuse holder until it is possible to manually remove the damaged fuse.
- Insert the new fuse in the fuse holder.
- Close the fuse holder by slightly pressing on it.
- Reposition and fix the machine rear panel using the previously removed screws.


AC LINE IN L	15	○ □ □ □ □	
AC LINE IN N	14	○ □ □ □ □	
24V SPB	13	○ □ □ □ □	5x20 F2A 250Vac
24V DOUBLE GROUP	12	○ □ □ □ □	5x20 F4A 250Vac
24V MMT	11	○ □ □ □ □	5x20 F2A 250Vac
24V PUMP 3/4/5	10	○ □ □ □ □	5x20 F2A 250Vac
48V DOUBLE GROUP	9	○ □ □ □ □	5x20 F4A 250Vac
48V MMT	8	○ □ □ □ □	5x20 F2.5A 250Vac
48V AIR HEATER	7	○ □ □ □ □	5x20 T6.3A 250Vac
48V PUMP 3/4/5	6	○ □ □ □ □	5x20 F4A 250Vac
24V PUMP 3/4/5	5	○ □ □ □ □	
48V PUMP 3/4/5	4	○ □ □ □ □	
DC GND	3	○ □ □ □ □	
DC GND	2	○ □ □ □ □	
DC GND	1	○ □ □ □ □	

WARNING: use only fuse of the same type and with the same nominal rating specified by the manufacturer.

3.4. REPLACING THE POWER SUPPLY UNITS

In case of an electric fault in one or more power supply units of the machine, proceed as follows to replace them:

- To reach the power supply unit compartment, remove the rear panel as described in chapter 2 - EXTERNAL COVER REMOVAL.
- Disconnect the wiring between the power supply unit to be replaced and the rest of the machine.
- Remove the power supply unit by fitting a small flat screwdriver in the suitable retaining tab and remove the unit from the DIN bar.




- Fit the new power supply unit manually on the DIN bar.
- Reconnect the power supply unit to the wiring according to the attached wiring diagram.
- Reposition the previously removed protection panel.

WARNING: use only genuine spare parts supplied by the manufacturer.

3.5. REPLACING THE PC AND MAIN BOARDS

To replace the PC (Linux or Raspberry) or Main (MAB or MMT) boards, proceed as follows:


- Remove the rear panel as described in chapter 2 - EXTERNAL COVER REMOVAL.
- Disconnect the power supply and signal cables from the board to be replaced.
- Remove the Main (1) or PC (2) board from the supports at the corners (pressure-fit plastic supports for the Main board and M3 retaining screws for the PC board).
- Insert a new board on the supports having care not to damage its components.
- **WARNING:** Use an already programmed board or the suitable programmer to install the correct software/firmware. To reprogramme the boards refer to chapter 4.
- Restore the electric connections.



3.6. REPLACING THE SEMI-FINISHED PRODUCT SCCB BOARD

The SCCB boards of the semi-finished product circuits (1), when present, are also located inside the electrical box. To replace them, proceed as follows:

- Remove the rear panel as described in chapter 2 - EXTERNAL COVER REMOVAL.
 - Disconnect the power supply and signal cables from the board to be replaced.
 - Remove the board by releasing it from the plastic supports on its corners.
-
- Insert a new board on the supports having care not to damage its components.
 - **WARNING:** Use a board already programmed with the function of the replaced board. To reprogramme the boards refer to chapter 4.
 - Restore the previously disconnected connections according to the wiring diagram.



3.7. REPLACING THE HUTTS BOARD

The board is located inside the cabinet, fixed on the back of the colorant support base.

To change the board, remove the top rear panel as described in Chap. 2 - REMOVING THE EXTERNAL COVERS, then:


- Disconnect board connector.
- Loosen the two M3 screws that secure the board to the support, then proceed with the replacement by restoring the connections.



3.8. REPLACING THE AUTOCAP PARTS

By removing the metal sheet protection on the autocap (1), held in place by 3 M3 screws at the sides, it is possible to access group driving parts, such as motor and photocells.

For targeted interventions on motor (2), open group photocell (3), closed group photocell (4), level sensor (5) and heater (6) contact the assistance service.



3.9. LTE ROUTER SETTINGS


When a hard-wired ethernet network is not available, it is still possible to obtain a remote connection to the machine via an LTE Router.

A VPN client - duly installed and set up - is necessary to connect to the machine.

3.9.1. CONNECTION VIA VPN CLIENT ON WINDOWS 7 AND 10


To install the VPN Client, proceed as described below:

- Open an internet browser at <https://openvpn.net/index.php/open-source/downloads.html>
- Click “openvpn-install-2.4.4-l601.exe” (1) and download the file.



NOTE: the GPG key used to sign the release files has been changed since OpenVPN 2.4.4-l601. The new GPG public key is available [here](#). We also provide static URLs pointing to latest releases to ease automation. For more information, see the [FAQ](#).

- Open the downloaded file, then press “Next” (2) on the following screen page.




- Check the boxes indicated in the figure on the side, then press “Next”.




To connect to the machine via the VPN Client, proceed as described below:

- Download the file containing the login credentials sent by Alfa via email.




- Save the file containing the credentials in C:/programs/OpenVPN/Config
- Make sure you save it as an “.opvn” file.




- On Windows Toolbar, click the arrow icon “show hidden icons” (3) then find the icon “OpenVPN” (4) in the pop-up.




- Right click on the icon and select “Connect” (5);



- Press “Hide” (6) to close the following page;




- After a few seconds a new pop-up will open on the toolbar, near the clock indicating that the PC is connected. This window could close automatically, while the OpenVPN icon will become green.



- To connect to the machine, open your internet browser.
- In the address bar, enter the IP address of the machine you wish to establish connection with, usually indicated on the LTE router.
- Enter the login credentials given by Alfa.

To disconnect from the machine, right click on OpenVPN icon and select “Disconnect” (7).



3.9.2. CONNECTION VIA VPN CLIENT FROM ANDROID DEVICES


To install the VPN Client, proceed as described below:

- From the Home screen of your device, open Play Store.
- In the search bar, type “openvpn for android”.
- Click the green button (1) to install the application.



To connect to the machine via the VPN Client, proceed as described below:


- Download the file containing the login credentials sent by Alfa via email.




- Run the app OpenVPN (2) previously installed.




- Press symbol “+” present on the bar at top right of the app screen.




- Press “Import” (3).




- Select the “.ovpn” file previously downloaded;



- Press on the check mark in the top right corner;




- Press on the just-added file (4).



- Press OK (5) on the next window.




- Now the VPN status must be “Connected” (6).



- To connect to the machine, open your internet browser.
- In the address bar, enter the IP address of the machine you wish to establish connection with, usually indicated on the LTE router.

Enter the login credentials given by Alfa.

- To disconnect from the machine, open the app OpenVPN, then select the “Profiles” menu and press “Disconnect” (7).



4. PROGRAMMING THE ELECTRONIC BOARDS

Depending on board version, programming can be carried out in either of two different methods:

- Boards without bootloader (programming through PICKit / ICD3).
- Boards with bootloader.

Alfa products are delivered with the Bootloader loaded on all boards.

Each FW update therefore includes the procedure using the BootLoaderAPP Software (also called AlfaUSBProgrammer), described in paragraph 4.2 below.

4.1. PROGRAMMING OF BOARDS WITH NO BOOTLOADER

The procedure through PICKit (or ICD3 for MMT and HUTBRD boards) is still necessary only to load the Boot on boards without it, in particular on first-generation machines. This procedure can only be performed by Alfa Service. Each spare part is shipped with the Boot already preloaded.

4.2. PROGRAMMING OF BOARDS WITH BOOTLOADER

4.2.1. SOFTWARE “BOOTLOADERAPP”

The most recent boards are preloaded with BOOT firmware for the management of the BootLoader, i.e. the application that allows the updating of the machine control firmware.

NOTE: To program a board that does not feature preloaded BOOT, please contact Alfa technical service.

To program a hard-wired board via BootLoaderAPP, it is necessary to follow this procedure:


1. Shut off the machine;
2. connect the special Alfa USB BOOT LOADER cable (code 305001893) across the dedicated connector of the Main board (CN13 for the MAB, CN5 for the MMT, if it is used instead of the MAB) and a USB port of the PC / LAPTOP on which the BootloaderAPP.exe application resides; Machine side, use the "BOOT" panel connector when present.
3. run BootloaderAPP;
4. switch the machine on.

TO USE A MACHINE IN BOOT MODE, YOU MUST FIRST CONNECT THE USB CABLE FROM MAB/MMT TO PC / LAPTOP AND THEN SWITCH MACHINE ON.


BootLoaderAPP installation procedure is described in the following paragraph. If the software is already installed on the PC, go directly to the following paragraph explaining software use for programming boards.

4.2.2. INSTALLATION OF “BOOTLOADERAPP”


If a version of the application is already present on the PC, you must first remove it before installing a new version.

In this case, run the installation software  **ALFA Boot Manager** and select option “Remove ALFA Boot Manager”, then press “Finish”.

Wait until uninstall is completed and press “Close”.




To install the application:

1. Run the installation file  **ALFA Boot Manager**.


The page on the side will open.



2. In the following window, select the software installation path and select option “Everyone”, then press “Next >”.




3. When prompted, press “Next >” until completing the installation procedure, then press “Close” to end the installation procedure.





4.2.3. STARTING THE BOOTLOADER

Run BootloaderApp on the PC (the application is in the folder selected in step 2 of the installation procedure).
The following window will open.




4.2.4. MAB FIRMWARE UPDATE

- Check that the software detected the presence of a MAB 'Device attached' (1)
- Select the MAB board to be used by pressing the MAB button (2) 'Selected target device is now MAB' + 'QueryVerify command sent to MAB BOOT LOADER'
- Select the Intel HEX file to be programmed, and press 'Open Hex File' (3) 'HEX File Complete'
- Proceed with Programming and Verification, by pressing 'Program/Verify' (4) ": wait for the final message 'Erase/Program/Verify Completed Successfully'
- If programming is successful, the 'MAB' button becomes GREEN.




4.2.5. UPDATING THE MMT FIRMWARE

- Check that the software detected the presence of a MMT 'Device attached' (1).
- Select the MAB board to be used by pressing the MAB button (2) 'Selected target device is now MAB' + 'QueryVerify command sent to MAB BOOT LOADER'.
- Select the Intel HEX file to be programmed, and press 'Open Hex File' (3) 'HEX File Complete'.
- Proceed with Programming and Verification, by pressing 'Program/Verify' (4) ": wait for the final message 'Erase/Program/Verify Completed Successfully'.
- If programming is successful, the 'MAB/Tinting' button becomes GREEN.



4.2.6. UPDATING THE ACTUATOR FIRMWARE (SCCB, MMT THOR 1.0 with BRUSH, HUTBRD THOR 1.0 BOARDS)

- Connect the special Alfa USB BOOT LOADER cable (code 305001893) across the dedicated connector of the Main board (CN13 for the MAB, CN5 for the MMT, if it is used instead of the MAB) and a USB port of the programming PC; Machine side, use the "BOOT" panel connector when present.
- Switch the machine on (or the board when programming it on a bench);
- Check that the software detected the presence of a MAB (MMT for Thor 2.0) 'Device attached';
- Select actuator board (1) to be programmed by pressing the corresponding button (Fig. C1) (2) 'Selected target device is now C1' + 'QueryVerify command sent to MAB BOOT LOADER' (MMT for Thor 2.0);
Check that the address set in the actuator board to be programmed is consistent with the selected device (please refer to the following paragraph "SETTING ADDRESSES");
NOTE: THE MMT BOARD FEATURES NO DIP SWITCH, ITS ADDRESS IS WIRED INTO THE FIXED FIRMWARE.
- Select the Intel HEX file to be programmed, and press 'Open Hex File' (3) 'HEX File Complete';
- Proceed with Programming and Verification, by pressing 'Program/Verify' (4), then wait for the final message 'Erase/Program/Verify Completed Successfully' (5);
- If programming is successful, the 'C1' button becomes GREEN.



4.2.7. SETTING ADDRESSES





For programming an SCCB actuator board, the address set via the dip-switches must be consistent with the Target selected via the programming software (see previous paragraph).

Before programming a board, set the corresponding dip-switches accordingly.

Dip-switch addressing is a binary code.

The less significant bit is the leftmost; A dip switch set to ON corresponds to a bit with a value equal to '1'.

SCCB boards must have a fixed addressing according to the following coding:

GROUP OR CIRCUIT	DIP-SWITCH
DOUBLE GROUP	
PUMP 3	
PUMP 4	
PUMP 5	

Each address must be unique in the machine.

After programming, board address can be changed but only into addresses belonging to the same group of circuits (colorants, bases, etc.).

5. HANDLING THE MACHINE

5.1. MOVING THE MACHINE

Machine Thor must be moved in full safety.

In order to move the machine with the cabinet, it is possible to raise the support feet and use the dedicated wheels.

IN ORDER TO AVOID THE RISK OF PAINTING SPILLS INSIDE THE MACHINE, NEVER MOVE THE MACHINE WITH THE COLORANT CIRCUITS FULL.

BEWARE OF ANY STEPS OR IRREGULARITIES IN THE FLOORING/TERRAIN THAT COULD RESULT IN SUDDEN STOPPAGES, AS THESE COULD CAUSE MACHINE TO BECOME UNBALANCED. ALWAYS PROCEED AT A LOW SPEED WITH TWO PEOPLE HANDLING THE MACHINE AT ALL TIMES.

For bigger movements, it is necessary to use a suitable lifting mean. In this case, proceed as follows:

- Switch the machine off and disconnect all electric connections (power supply, ethernet, etc.);
- Remove PC, keyboard, monitor and any other device from the machine bearing surfaces;
- Push the machine on the forks of a forklift truck or a manual lift truck having a suitable capacity, after checking the weight of the configuration in section 1.5 – DIMENSIONS AND WEIGHT of the operator's manual;

EMPTY ALL TANKS OR BRING THEM TO MINIMUM LEVEL BEFORE LIFTING AND/OR MOVING THE MACHINE. BASED ON THE MOVEMENT TO BE MADE, CHECK FOR THE POSSIBLE NEED TO LOCK ALL MOBILE PARTS BY RESTORING THE LOCKS SPECIFIED IN CHAP.3 – INSTALLATION – OF THE OPERATOR'S MANUAL.

LIFT THE MACHINE CAREFULLY, TAKING CARE TO MAKE SURE THAT IT IS GRIPPED PROPERLY AND IS NOT AT RISK OF TIPPING OVER

- Handle the machine using the fork lift truck and position it in the installation space.

Always place the machine on a surface suitable for sustaining its weight or on perfectly smooth and level flooring.

Once the movement has been completed, lower the support feet to stabilise the machine and reconnect the electrical circuits. Use a spirit-level to level the machine.

6. ACCESS TO THE DIAGNOSTIC FUNCTIONS


6.1. ADMIN CONTROL AND DIAGNOSTIC INTERFACE

The web control browser Admin interface has diagnostic functions that indicate the status of the machine and of the relevant circuits, as well as specific controls to activate and test each single circuit or the valve and motor functions.


For information about the interface access modes and the function description refer to the software manual.

7. CONNECTION DIAGRAMS


DOUBLE GROUP




PUMP 3




PUMP 4




PUMP 5





HISTORY									
NO.	DATE	MODIFICATION	BY	DATE	REASON	NO.	DATE	MODIFICATION	BY
1	2020/01/20	1	2020/01/20	1	2020/01/20	1	2020/01/20	1	2020/01/20
2	2020/01/20	2	2020/01/20	2	2020/01/20	2	2020/01/20	2	2020/01/20
3	2020/01/20	3	2020/01/20	3	2020/01/20	3	2020/01/20	3	2020/01/20
4	2020/01/20	4	2020/01/20	4	2020/01/20	4	2020/01/20	4	2020/01/20
5	2020/01/20	5	2020/01/20	5	2020/01/20	5	2020/01/20	5	2020/01/20
6	2020/01/20	6	2020/01/20	6	2020/01/20	6	2020/01/20	6	2020/01/20
7	2020/01/20	7	2020/01/20	7	2020/01/20	7	2020/01/20	7	2020/01/20
8	2020/01/20	8	2020/01/20	8	2020/01/20	8	2020/01/20	8	2020/01/20
9	2020/01/20	9	2020/01/20	9	2020/01/20	9	2020/01/20	9	2020/01/20
10	2020/01/20	10	2020/01/20	10	2020/01/20	10	2020/01/20	10	2020/01/20
11	2020/01/20	11	2020/01/20	11	2020/01/20	11	2020/01/20	11	2020/01/20
12	2020/01/20	12	2020/01/20	12	2020/01/20	12	2020/01/20	12	2020/01/20
13	2020/01/20	13	2020/01/20	13	2020/01/20	13	2020/01/20	13	2020/01/20
14	2020/01/20	14	2020/01/20	14	2020/01/20	14	2020/01/20	14	2020/01/20
15	2020/01/20	15	2020/01/20	15	2020/01/20	15	2020/01/20	15	2020/01/20
16	2020/01/20	16	2020/01/20	16	2020/01/20	16	2020/01/20	16	2020/01/20
17	2020/01/20	17	2020/01/20	17	2020/01/20	17	2020/01/20	17	2020/01/20
18	2020/01/20	18	2020/01/20	18	2020/01/20	18	2020/01/20	18	2020/01/20
19	2020/01/20	19	2020/01/20	19	2020/01/20	19	2020/01/20	19	2020/01/20
20	2020/01/20	20	2020/01/20	20	2020/01/20	20	2020/01/20	20	2020/01/20
21	2020/01/20	21	2020/01/20	21	2020/01/20	21	2020/01/20	21	2020/01/20
22	2020/01/20	22	2020/01/20	22	2020/01/20	22	2020/01/20	22	2020/01/20
23	2020/01/20	23	2020/01/20	23	2020/01/20	23	2020/01/20	23	2020/01/20
24	2020/01/20	24	2020/01/20	24	2020/01/20	24	2020/01/20	24	2020/01/20
25	2020/01/20	25	2020/01/20	25	2020/01/20	25	2020/01/20	25	2020/01/20
26	2020/01/20	26	2020/01/20	26	2020/01/20	26	2020/01/20	26	2020/01/20
27	2020/01/20	27	2020/01/20	27	2020/01/20	27	2020/01/20	27	2020/01/20
28	2020/01/20	28	2020/01/20	28	2020/01/20	28	2020/01/20	28	2020/01/20
29	2020/01/20	29	2020/01/20	29	2020/01/20	29	2020/01/20	29	2020/01/20
30	2020/01/20	30	2020/01/20	30	2020/01/20	30	2020/01/20	30	2020/01/20
31	2020/01/20	31	2020/01/20	31	2020/01/20	31	2020/01/20	31	2020/01/20
32	2020/01/20	32	2020/01/20	32	2020/01/20	32	2020/01/20	32	2020/01/20
33	2020/01/20	33	2020/01/20	33	2020/01/20	33	2020/01/20	33	2020/01/20
34	2020/01/20	34	2020/01/20	34	2020/01/20	34	2020/01/20	34	2020/01/20
35	2020/01/20	35	2020/01/20	35	2020/01/20	35	2020/01/20	35	2020/01/20
36	2020/01/20	36	2020/01/20	36	2020/01/20	36	2020/01/20	36	2020/01/20
37	2020/01/20	37	2020/01/20	37	2020/01/20	37	2020/01/20	37	2020/01/20
38	2020/01/20	38	2020/01/20	38	2020/01/20	38	2020/01/20	38	2020/01/20
39	2020/01/20	39	2020/01/20	39	2020/01/20	39	2020/01/20	39	2020/01/20
40	2020/01/20	40	2020/01/20	40	2020/01/20	40	2020/01/20	40	2020/01/20
41	2020/01/20	41	2020/01/20	41	2020/01/20	41	2020/01/20	41	2020/01/20
42	2020/01/20	42	2020/01/20	42	2020/01/20	42	2020/01/20	42	2020/01/20
43	2020/01/20	43	2020/01/20	43	2020/01/20	43	2020/01/20	43	2020/01/20
44	2020/01/20	44	2020/01/20	44	2020/01/20	44	2020/01/20	44	2020/01/20
45	2020/01/20	45	2020/01/20	45	2020/01/20	45	2020/01/20	45	2020/01/20
46	2020/01/20	46	2020/01/20	46	2020/01/20	46	2020/01/20	46	2020/01/20
47	2020/01/20	47	2020/01/20	47	2020/01/20	47	2020/01/20	47	2020/01/20
48	2020/01/20	48	2020/01/20	48	2020/01/20	48	2020/01/20	48	2020/01/20
49	2020/01/20	49	2020/01/20	49	2020/01/20	49	2020/01/20	49	2020/01/20
50	2020/01/20	50	2020/01/20	50	2020/01/20	50	2020/01/20	50	2020/01/20
51	2020/01/20	51	2020/01/20	51	2020/01/20	51	2020/01/20	51	2020/01/20
52	2020/01/20	52	2020/01/20	52	2020/01/20	52	2020/01/20	52	2020/01/20
53	2020/01/20	53	2020/01/20	53	2020/01/20	53	2020/01/20	53	2020/01/20
54	2020/01/20	54	2020/01/20	54	2020/01/20	54	2020/01/20	54	2020/01/20
55	2020/01/20	55	2020/01/20	55	2020/01/20	55	2020/01/20	55	2020/01/20
56	2020/01/20	56	2020/01/20	56	2020/01/20	56	2020/01/20	56	2020/01/20
57	2020/01/20	57	2020/01/20	57	2020/01/20	57	2020/01/20	57	2020/01/20
58	2020/01/20	58	2020/01/20	58	2020/01/20	58	2020/01/20	58	2020/01/20
59	2020/01/20	59	2020/01/20	59	2020/01/20	59	2020/01/20	59	2020/01/20
60	2020/01/20	60	2020/01/20	60	2020/01/20	60	2020/01/20	60	2020/01/20
61	2020/01/20	61	2020/01/20	61	2020/01/20	61	2020/01/20	61	2020/01/20
62	2020/01/20	62	2020/01/20	62	2020/01/20	62	2020/01/20	62	2020/01/20
63	2020/01/20	63	2020/01/20	63	2020/01/20	63	2020/01/20	63	2020/01/20
64	2020/01/20	64	2020/01/20	64	2020/01/20	64	2020/01/20	64	2020/01/20
65	2020/01/20	65	2020/01/20	65	2020/01/20	65	2020/01/20	65	2020/01/20
66	2020/01/20	66	2020/01/20	66	2020/01/20	66	2020/01/20	66	2020/01/20
67	2020/01/20	67	2020/01/20	67	2020/01/20	67	2020/01/20	67	2020/01/20
68	2020/01/20	68	2020/01/20	68	2020/01/20	68	2020/01/20	68	2020/01/20
69	2020/01/20	69	2020/01/20	69	2020/01/20	69	2020/01/20	69	2020/01/20
70	2020/01/20	70	2020/01/20	70	2020/01/20	70	2020/01/20	70	2020/01/20
71	2020/01/20	71	2020/01/20	71	2020/01/20	71	2020/01/20	71	2020/01/20
72	2020/01/20	72	2020/01/20	72	2020/01/20	72	2020/01/20	72	2020/01/20
73	2020/01/20	73	2020/01/20	73	2020/01/20	73	2020/01/20	73	2020/01/20
74	2020/01/20	74	2020/01/20	74	2020/01/20	74	2020/01/20	74	2020/01/20
75	2020/01/20	75	2020/01/20	75	2020/01/20	75	2020/01/20	75	2020/01/20
76	2020/01/20	76	2020/01/20	76	2020/01/20	76	2020/01/20	76	2020/01/20
77	2020/01/20	77	2020/01/20	77	2020/01/20	77	2020/01/20	77	2020/01/20
78	2020/01/20	78	2020/01/20	78	2020/01/20	78	2020/01/20	78	2020/01/20
79	2020/01/20	79	2020/01/20	79	2020/01/20	79	2020/01/20	79	2020/01/20
80	2020/01/20	80	2020/01/20	80	2020/01/20	80	2020/01/20	80	2020/01/20
81	2020/01/20	81	2020/01/20	81	2020/01/20	81	2020/01/20	81	2020/01/20
82	2020/01/20	82	2020/01/20	82	2020/01/20	82	2020/01/20	82	2020/01/20
83	2020/01/20	83	2020/01/20	83	2020/01/20	83	2020/01/20	83	2020/01/20
84	2020/01/20	84	2020/01/20	84	2020/01/20	84	2020/01/20	84	2020/01/20
85	2020/01/20	85	2020/01/20	85	2020/01/20	85	2020/01/20	85	2020/01/20
86	2020/01/20	86	2020/01/20	86	2020/01/20	86	2020/01/20	86	2020/01/20
87	2020/01/20	87	2020/01/20	87	2020/01/20	87	2020/01/20	87	2020/01/20
88	2020/01/20	88	2020/01/20	88	2020/01/20	88	2020/01/20	88	2020/01/20
89	2020/01/20	89	2020/01/20	89	2020/01/20	89	2020/01/20	89	2020/01/20
90	2020/01/20	90	2020/01/20	90	2020/01/20	90	2020/01/20	90	2020/01/20
91	2020/01/20	91	2020/01/20	91	2020/01/20	91	2020/01/20	91	2020/01/20
92	2020/01/20	92	2020/01/20	92	2020/01/20	92	2020/01/20	92	2020/01/20
93	2020/01/20	93	2020/01/20	93	2020/01/20	93	2020/01/20	93	2020/01/20
94	2020/01/20	94	2020/01/20	94	2020/01/20	94	2020/01/20	94	2020/01/20
95	2020/01/20	95	2020/01/20	95	2020/01/20	95	2020/01/20	95	2020/01/20
96	2020/01/20	96	2020/01/20	96	2020/01/20	96	2020/01/20	96	2020/01/20
97	2020/01/20	97	2020/01/20	97	2020/01/20	97	2020/01/20	97	2020/01/20
98	2020/01/20	98	2020/01/20	98	2020/01/20	98	2020/01/20	98	2020/01/20
99	2020/01/20	99	2020/01/20	99	2020/01/20	99	2020/01/20	99	2020/01/20
100	2020/01/20	100	2020/01/20	100	2020/01/20	100	2020/01/20	100	2020/01/20
101	2020/01/20	101	2020/01/20	101	2020/01/20	101	2020/01/20	101	2020/01/20
102	2020/01/20	102	2020/01/20	102	2020/01/20	102	2020/01/20	102	2020/01/20
103	2020/01/20	103	2020/01/20	103	2020/01/20	103	2020/01/20	103	2020/01/20
104	2020/01/20	104	2020/01/20	104	2020/01/20	104	2020/01/20	104	2020/01/20
105	2020/01/20	105	2020/01/20	105	2020/01/20	105	2020/01/20	105	2020/01/20
106	2020/01/20	106	2020/01/20	106	2020/01/20	106	2020/01/20	106	2020/01/20
107	2020/01/20	107	2020/01/20	107	2020/01/20	107	2020/01/20	107	2020/01/20
108	2020/01/20	108	2020/01/20	108	2020/01/20	108	2020/01/20	108	202


TO CONTINUED




305002360

TINTING MOTOR


PC LINUX



SLAVE PUMP 3




PW PROGRAMMING CONNECTION





REVISION			
Rev.	Date	Modifications	Author
1	11/11/11	1	11/11/11
2	11/11/11	2	11/11/11
3	11/11/11	3	11/11/11
4	11/11/11	4	11/11/11
5	11/11/11	5	11/11/11
6	11/11/11	6	11/11/11
7	11/11/11	7	11/11/11
8	11/11/11	8	11/11/11
9	11/11/11	9	11/11/11
10	11/11/11	10	11/11/11
11	11/11/11	11	11/11/11
12	11/11/11	12	11/11/11
13	11/11/11	13	11/11/11
14	11/11/11	14	11/11/11
15	11/11/11	15	11/11/11
16	11/11/11	16	11/11/11
17	11/11/11	17	11/11/11
18	11/11/11	18	11/11/11
19	11/11/11	19	11/11/11
20	11/11/11	20	11/11/11
21	11/11/11	21	11/11/11
22	11/11/11	22	11/11/11
23	11/11/11	23	11/11/11
24	11/11/11	24	11/11/11
25	11/11/11	25	11/11/11
26	11/11/11	26	11/11/11
27	11/11/11	27	11/11/11
28	11/11/11	28	11/11/11
29	11/11/11	29	11/11/11
30	11/11/11	30	11/11/11
31	11/11/11	31	11/11/11
32	11/11/11	32	11/11/11
33	11/11/11	33	11/11/11
34	11/11/11	34	11/11/11
35	11/11/11	35	11/11/11
36	11/11/11	36	11/11/11
37	11/11/11	37	11/11/11
38	11/11/11	38	11/11/11
39	11/11/11	39	11/11/11
40	11/11/11	40	11/11/11
41	11/11/11	41	11/11/11
42	11/11/11	42	11/11/11
43	11/11/11	43	11/11/11
44	11/11/11	44	11/11/11
45	11/11/11	45	11/11/11
46	11/11/11	46	11/11/11
47	11/11/11	47	11/11/11
48	11/11/11	48	11/11/11
49	11/11/11	49	11/11/11
50	11/11/11	50	11/11/11
51	11/11/11	51	11/11/11
52	11/11/11	52	11/11/11
53	11/11/11	53	11/11/11
54	11/11/11	54	11/11/11
55	11/11/11	55	11/11/11
56	11/11/11	56	11/11/11
57	11/11/11	57	11/11/11
58	11/11/11	58	11/11/11
59	11/11/11	59	11/11/11
60	11/11/11	60	11/11/11
61	11/11/11	61	11/11/11
62	11/11/11	62	11/11/11
63	11/11/11	63	11/11/11
64	11/11/11	64	11/11/11
65	11/11/11	65	11/11/11
66	11/11/11	66	11/11/11
67	11/11/11	67	11/11/11
68	11/11/11	68	11/11/11
69	11/11/11	69	11/11/11
70	11/11/11	70	11/11/11
71	11/11/11	71	11/11/11
72	11/11/11	72	11/11/11
73	11/11/11	73	11/11/11
74	11/11/11	74	11/11/11
75	11/11/11	75	11/11/11
76	11/11/11	76	11/11/11
77	11/11/11	77	11/11/11
78	11/11/11	78	11/11/11
79	11/11/11	79	11/11/11
80	11/11/11	80	11/11/11
81	11/11/11	81	11/11/11
82	11/11/11	82	11/11/11
83	11/11/11	83	11/11/11
84	11/11/11	84	11/11/11
85	11/11/11	85	11/11/11
86	11/11/11	86	11/11/11
87	11/11/11	87	11/11/11
88	11/11/11	88	11/11/11
89	11/11/11	89	11/11/11
90	11/11/11	90	11/11/11
91	11/11/11	91	11/11/11
92	11/11/11	92	11/11/11
93	11/11/11	93	11/11/11
94	11/11/11	94	11/11/11
95	11/11/11	95	11/11/11
96	11/11/11	96	11/11/11
97	11/11/11	97	11/11/11
98	11/11/11	98	11/11/11
99	11/11/11	99	11/11/11
100	11/11/11	100	11/11/11

SLAVE PUMP 4

[illegible]


SLAVE PUMP 5

02LT 3

[illegible]

TERMINAL BOX

- PIN1 + FOT TABLE
 PIN2 - FOT TABLE
 PIN3 IN FOT TABLE
 PIN4 + FOT VALVE RIGHT LITTLE HOLE
 PIN5 - FOT VALVE RIGHT LITTLE HOLE
 PIN6 IN FOT VALVE RIGHT LITTLE HOLE
 PIN7 + FOT PUMP CONNECTION
 PIN8 - FOT PUMP CONNECTION
 PIN9 IN FOT PUMP CONNECTION
 PIN10 + FOT PUMP HOME
 PIN11 - FOT PUMP HOME
 PIN12 IN FOT PUMP HOME
 PIN13 + FOT VALVE LEFT BIG HOLE
 PIN14 - FOT VALVE LEFT BIG HOLE
 PIN15 IN FOT VALVE LEFT BIG HOLE



TINTING MOTOR CONNECTION

- PIN1 STEPPER TABLE
 PIN2 STEPPER PUMP
 PIN3 STEPPER VALVE
 PIN4 STEPPER TABLE
 PIN5 STEPPER PUMP
 PIN6 STEPPER VALVE
 PIN7 STEPPER TABLE
 PIN8 STEPPER PUMP
 PIN9 STEPPER VALVE
 PIN10 STEPPER TABLE
 PIN11 STEPPER PUMP
 PIN12 STEPPER VALVE
 PIN13
 PIN14
 PIN15



BRUSH CONNECTION

- PIN1 + FOT BRUSH HOME
 PIN2 - FOT BRUSH HOME
 PIN3 IN FOT BRUSH HOME
 PIN4 BRUSH DC
 PIN5 BRUSH DC
 PIN6
 PIN7 -
 PIN8 -
 PIN9
 PIN10
 PIN11 -
 PIN12 -
 PIN13
 PIN14 -
 PIN15



I/O CONNECTION

- PIN1 - STATUS LED
 PIN2 - STATUS LED
 PIN3
 PIN4 IN CAN PRESECE SENSOR
 PIN5 - CAN PRESECE SENSOR
 PIN6 + CAN PRESECE SENSOR
 PIN7 SENS PRES TROLLEY
 PIN8 SENS PRES TROLLEY
 PIN9 + LASER
 PIN10 - STOP BUTTON
 PIN11 STOP BUTTON
 PIN12 - LASER
 PIN13
 PIN14 SENS TABLE DOOR
 PIN15 SENS TABLE DOOR



AUTOCAP. HUMIDIFIER CONNECTION

- PIN1 + FOT ACAP CLOSE
 PIN2 - FOT ACAP CLOSE
 PIN3 IN FOT ACAP CLOSE
 PIN4 + FOT ACAP OPEN
 PIN5 - FOT ACAP OPEN
 PIN6 IN FOT ACAP OPEN
 PIN7
 PIN8
 PIN9
 PIN10 RESERVE
 PIN11 + WATER RESISTOR
 PIN12 - WATER RESISTOR
 PIN13 RESERVE
 PIN14 DC ACAP
 PIN15 DC ACAP




AIR HEATER CONNECTION


- PIN1 AIR HEATER
 PIN2 AIR HEATER
 PIN3
 PIN4 AIR TEMPERATURE SENS
 PIN5 AIR TEMPERATURE SENS
 PIN6 AIR TEMPERATURE SENS
 PIN7 AIR TEMPERATURE SENS
 PIN8 AIR TEMPERATURE SENS
 PIN9 AIR TEMPERATURE SENS



AIR HEATER RELE



-V --- 24V/48V



- PIN IN FOT HOME
 PIN2 -V SENSOR
 PIN3 +V SENSOR
 PIN4 + STIR
 PIN5 - E VALVE
 PIN6 + E VALVE
 PIN7 - STIR
 PIN8
 PIN9
 PIN10
 PIN11 STEPPER
 PIN12 STEPPER
 PIN13
 PIN14 STEPPER
 PIN15 STEPPER



- PIN IN FOT HOME
 PIN2 -V SENSOR
 PIN3 +V SENSOR
 PIN4 + STIR
 PIN5 - E VALVE
 PIN6 + E VALVE
 PIN7 - STIR
 PIN8
 PIN9
 PIN10
 PIN11 STEPPER
 PIN12 STEPPER
 PIN13
 PIN14 STEPPER
 PIN15 STEPPER



- PIN IN FOT HOME
 PIN2 -V SENSOR
 PIN3 +V SENSOR
 PIN4 + STIR
 PIN5 - E VALVE
 PIN6 + E VALVE
 PIN7 - STIR
 PIN8
 PIN9
 PIN10
 PIN11 STEPPER
 PIN12 STEPPER
 PIN13
 PIN14 STEPPER
 PIN15 STEPPER



- PIN IN FOT HOME
 PIN2 -V SENSOR
 PIN3 +V SENSOR
 PIN4 - SLAVE E VALVE
 PIN5 - MASTER E VALVE
 PIN6 + MASTER E VALVE
 PIN7 + SLAVE E VALVE
 PIN8
 PIN9
 PIN10 - STIR
 PIN11 STEPPER
 PIN12 STEPPER
 PIN13 - STIR
 PIN14 STEPPER
 PIN15 STEPPER

THIS HISTORY			
Rev	Change	By	Approved
1	1.0	1.0	1.0
2	1.1	1.1	1.1
3	1.2	1.2	1.2
4	1.3	1.3	1.3
5	1.4	1.4	1.4
6	1.5	1.5	1.5
7	1.6	1.6	1.6
8	1.7	1.7	1.7
9	1.8	1.8	1.8
10	1.9	1.9	1.9
11	2.0	2.0	2.0
12	2.1	2.1	2.1
13	2.2	2.2	2.2
14	2.3	2.3	2.3
15	2.4	2.4	2.4
16	2.5	2.5	2.5
17	2.6	2.6	2.6
18	2.7	2.7	2.7
19	2.8	2.8	2.8
20	2.9	2.9	2.9
21	3.0	3.0	3.0
22	3.1	3.1	3.1
23	3.2	3.2	3.2
24	3.3	3.3	3.3
25	3.4	3.4	3.4
26	3.5	3.5	3.5
27	3.6	3.6	3.6
28	3.7	3.7	3.7
29	3.8	3.8	3.8
30	3.9	3.9	3.9
31	4.0	4.0	4.0
32	4.1	4.1	4.1
33	4.2	4.2	4.2
34	4.3	4.3	4.3
35	4.4	4.4	4.4
36	4.5	4.5	4.5
37	4.6	4.6	4.6
38	4.7	4.7	4.7
39	4.8	4.8	4.8
40	4.9	4.9	4.9
41	5.0	5.0	5.0
42	5.1	5.1	5.1
43	5.2	5.2	5.2
44	5.3	5.3	5.3
45	5.4	5.4	5.4
46	5.5	5.5	5.5
47	5.6	5.6	5.6
48	5.7	5.7	5.7
49	5.8	5.8	5.8
50	5.9	5.9	5.9
51	6.0	6.0	6.0
52	6.1	6.1	6.1
53	6.2	6.2	6.2
54	6.3	6.3	6.3
55	6.4	6.4	6.4
56	6.5	6.5	6.5
57	6.6	6.6	6.6
58	6.7	6.7	6.7
59	6.8	6.8	6.8
60	6.9	6.9	6.9
61	7.0	7.0	7.0
62	7.1	7.1	7.1
63	7.2	7.2	7.2
64	7.3	7.3	7.3
65	7.4	7.4	7.4
66	7.5	7.5	7.5
67	7.6	7.6	7.6
68	7.7	7.7	7.7
69	7.8	7.8	7.8
70	7.9	7.9	7.9
71	8.0	8.0	8.0
72	8.1	8.1	8.1
73	8.2	8.2	8.2
74	8.3	8.3	8.3
75	8.4	8.4	8.4
76	8.5	8.5	8.5
77	8.6	8.6	8.6
78	8.7	8.7	8.7
79	8.8	8.8	8.8
80	8.9	8.9	8.9
81	9.0	9.0	9.0
82	9.1	9.1	9.1
83	9.2	9.2	9.2
84	9.3	9.3	9.3
85	9.4	9.4	9.4
86	9.5	9.5	9.5
87	9.6	9.6	9.6
88	9.7	9.7	9.7
89	9.8	9.8	9.8
90	9.9	9.9	9.9
91	10.0	10.0	10.0
92	10.1	10.1	10.1
93	10.2	10.2	10.2
94	10.3	10.3	10.3
95	10.4	10.4	10.4
96	10.5	10.5	10.5
97	10.6	10.6	10.6
98	10.7	10.7	10.7
99	10.8	10.8	10.8
100	10.9	10.9	10.9
101	11.0	11.0	11.0
102	11.1	11.1	11.1
103	11.2	11.2	11.2
104	11.3	11.3	11.3
105	11.4	11.4	11.4
106	11.5	11.5	11.5
107	11.6	11.6	11.6
108	11.7	11.7	11.7
109	11.8	11.8	11.8
110	11.9	11.9	11.9
111	12.0	12.0	12.0
112	12.1	12.1	12.1
113	12.2	12.2	12.2
114	12.3	12.3	12.3
115	12.4	12.4	12.4
116	12.5	12.5	12.5
117	12.6	12.6	12.6
118	12.7	12.7	12.7
119	12.8	12.8	12.8
120	12.9	12.9	12.9
121	13.0	13.0	13.0
122	13.1	13.1	13.1
123	13.2	13.2	13.2
124	13.3	13.3	13.3
125	13.4	13.4	13.4
126	13.5	13.5	13.5
127	13.6	13.6	13.6
128	13.7	13.7	13.7
129	13.8	13.8	13.8
130	13.9	13.9	13.9
131	14.0	14.0	14.0
132	14.1	14.1	14.1
133	14.2	14.2	14.2
134	14.3	14.3	14.3
135	14.4	14.4	14.4
136	14.5	14.5	14.5
137	14.6	14.6	14.6
138	14.7	14.7	14.7
139	14.8	14.8	14.8
140	14.9	14.9	14.9
141	15.0	15.0	15.0
142	15.1	15.1	15.1
143	15.2	15.2	15.2
144	15.3	15.3	15.3
145	15.4	15.4	15.4
146	15.5	15.5	15.5
147	15.6	15.6	15.6
148	15.7	15.7	15.7
149	15.8	15.8	15.8
150	15.9	15.9	15.9
151	16.0	16.0	16.0
152	16.1	16.1	16.1
153	16.2	16.2	16.2
154	16.3	16.3	16.3
155	16.4	16.4	16.4
156	16.5	16.5	16.5
157	16.6	16.6	16.6
158	16.7	16.7	16.7
159	16.8	16.8	16.8
160	16.9	16.9	16.9
161	17.0	17.0	17.0
162	17.1	17.1	17.1
163	17.2	17.2	17.2
164	17.3	17.3	17.3
165	17.4	17.4	17.4
166	17.5	17.5	17.5
167	17.6	17.6	17.6
168	17.7	17.7	17.7
169	17.8	17.8	17.8
170	17.9	17.9	17.9
171	18.0	18.0	18.0
172	18.1	18.1	18.1
173	18.2	18.2	18.2
174	18.3	18.3	18.3
175	18.4	18.4	18.4
176	18.5	18.5	18.5
177	18.6	18.6	18.6
178	18.7	18.7	18.7
179	18.8	18.8	18.8
180	18.9	18.9	18.9
181	19.0	19.0	19.0
182	19.1	19.1	19.1
183	19.2	19.2	19.2
184	19.3	19.3	19.3
185	19.4	19.4	19.4
186	19.5	19.5	19.5
187	19.6	19.6	19.6
188	19.7	19.7	19.7
189	19.8	19.8	19.8
190	19.9	19.9	19.9
191	20.0	20.0	20.0
192	20.1	20.1	20.1
193	20.2	20.2	20.2
194	20.3	20.3	20.3
195	20.4	20.4	20.4
196	20.5	20.5	20.5
197	20.6	20.6	20.6
198	20.7	20.7	20.7
199	20.8	20.8	20.8
200	20.9	20.9	20.9
201	21.0	21.0	21.0
202	21.1	21.1	21.1
203	21.2	21.2	21.2
204	21.3	21.3	21.3
205	21.4	21.4	21.4
206	21.5	21.5	21.5
207	21.6	21.6	21.6
208	21.7	21.7	21.7
209	21.8	21.8	21.8
210	21.9	21.9	21.9
211	22.0	22.0	22.0
212	22.1	22.1	22.1
213	22.2	22.2	22.2
214	22.3	22.3	22.3
215	22.4	22.4	22.4
216	22.5	22.5	22.5
217	22.6	22.6	22.6
218	22.7	22.7	22.7
219	22.8	22.8	22.8
220	22.9	22.9	22.9
221	23.0	23.0	23.0
222	23.1	23.1	23.1
223	23.2	23.2	23.2
224	23.3	23.3	23.3
225	23.4	23.4	23.4
226	23.5	23.5	23.5
227	23.6	23.6	23.6
228	23.7	23.7	23.7
229	23.8	23.8	23.8
230	23.9	23.9	23.9
231	24.0	24.0	24.0
232	24.1	24.1	24.1
233	24.2	24.2	24.2
234	24.3	24.3	24.3
235	24.4	24.4	24.4
236	24.5	24.5	24.5
237	24.6	24.6	24.6
238	24.7	24.7	24.7
239	24.8	24.8	24.8
240	24.9	24.9	24.9
241	25.0	25.0	25.0
242	25.1	25.1	25.1
243	25.2	25.2	25.2